



# MINISLIDE MSQscale measuring system

Distance measuring system integrated into the MINISLIDE MSQ micro frictionless table

Product catalog 2019

### Latest version of the catalogs

You can always find the latest version of our catalogs in the Download area of our website.

## Disclaimer

This publication has been compiled with great care and all information has been checked for accuracy. However, we can assume no liability for incorrect or incomplete information. We reserve the right to make changes to the information and technical data as a result of enhancements to our products. Reprinting or reproducing, even in part, is not permitted without our written consent.



# Page number

1 MINISLIDE MSQscale Product Overview				4
	11	Technical Data		6

MINIS	SLIDE MSQscale Product Characteristics	7
2.1	High Speed and Acceleration	7
2.2	High Process Reliability thanks to Cage Control	7
2.3	Maximum Rigidity and Load Capacities	8
2.4	Reference and Supporting Surfaces	8
2.5	Running Accuracy and Parallelism of Supporting Surfaces	8
2.6	Tolerance of the Total Height	9
2.7	Push Force and Preload	9
2.8	Friction and Smoothness	9

MINISLIDE MSQscale Working Method and Components		
3.1	Dimensional Scale and Optical Sensor	10
3.2	Interface Module	12
3.3	Lubrication	15

4	Options		
	4.1	Interface Modules	16
	4.2	Digital Interface Module Resolution	16
	4.3	Height Adjusted (HA)	16
	4.4	Customer-specific Lubrication (KB)	16
	4.5	Linearity Protocol	16

5	Accessories		17
	5.1	Extensions	17
	5.2	MINISLIDE MSQscale Counter and Position Indicator	18

6	Dime	ension Tables, Load Capacities, Weights and Moment Loads	19
	6.1	MSQS 7	19
	6.2	MSQS 9	20
	6.3	MSQS 12	21
	6.4	MSQS 15	22

Load	Load Carrying Capacity and Service Life		
7.1	Principles	23	
7.2	Calculation of Service Life L in Accordance with the DIN ISO Standard	24	

8 Ordering Information

# MINISLIDE MSQscale Product Overview



Product range of MINISLIDE MSQscale

Demanding applications demand special guideways. This extraordinary innovation combines guiding and measuring functions in a highly integrated design. MINISLIDE MSQscale makes the most compact applications possible and significantly simplifies assembly and installation. Thus, the MINISLIDE MSQscale is an extremely economical solution that meets stringent technical requirements.

The MINISLIDE MSQscale is based on our MINISLIDE MSQ guideways. MINISLIDE MSQ embodies the latest generation of miniature guideways for very demanding applications. They are extremely robust and prove themselves in every application requiring low friction, precise motion.

The guideway has a highly precise, optical, incremental measuring system. The dimensional scale and sensor are perfectly integrated into the guideway.

The MINISLIDE MSQscale range includes sizes 7, 9, 12 and 15 with travel distances from 20 to 102 mm.

# MINISLIDE MSQscale Product Overview



High level of reliability and long service life • The MSQscale

The MSQscale is based on the successful MINISLIDE MSQ design and the proven measuring technology of the MINISCALE Plus

# MINISLIDE MSQscale Product Overview

# 1.1 Technical Data

Max. acceleration	300 m/s <sup>2</sup>
Max. speed	3 m/s
Preload	Zero backlash
Accuracy of guideway	See chapter 2.5
Areas of application:	
Temperature range (1)	-40 °C to +80 °C (-40 °F to +176 °F)
Humidity	10 % - 70 % (non-condensing)
Vacuum compatibility (2)	High vacuum (10 <sup>-7</sup> mbar)
Cleanroom compatibility	Cleanroom class ISO 7 and ISO 6 (in accordance with ISO 14644-1)
Materials:	
Guideways, carriages, balls	Stainless steel, through-hardened
Cage and pinion	PEEK
End pieces	PEEK
Resolution	TTL output 0.1 $\mu m$ $^{\scriptscriptstyle (3)}$ (optional: 1 $\mu m$ / 10 $\mu m)$
Accuracy of measuring system (4)	+/- 3 μm
Repeatability (4)	Unidirectional +/- 0.1 $\mu m$ Bidirectional +/- 0.2 $\mu m$ (with resolution of 0,1 $\mu m$ )
Dimensional scale	Pitch 100 μm Coefficient of expansion 11.7 x 10 <sup>-6</sup> K <sup>-1</sup>
Supply voltage	5 V DC +/- 5 %
Current consumption	60 mA (analog) / 70 mA (digital)
Output signal	Analog: 1 Vss Digital: TTL in accordance with RS 422 standard
Source format	Analog: Differential sin/cos analog signals with reference pulse or Digital: Differential, interpolated digital signals (A, B, R) The reference signal is synchronised with the incremental signals

- <sup>(1)</sup> The standard lubrication covers a temperature range from -20° C to +80° C. Lubricants for other temperatures are available upon request from SCHNEEBERGER (see chapter 4.4).
- <sup>(2)</sup> The suitability for a vacuum depends on the materials used. In order to use MSQscale in a vacuum, the fastening screws and front plates must be removed. There are also restrictions on the use of sensor accessories. Use in a vacuum requires a special lubricant available from SCHNEEBERGER. Please contact your SCHNEEBERGER representative for details on vacuum application.

<sup>(3)</sup> Note the high signal frequencies at high resolution and high speed.

<sup>(4)</sup> The values apply at 20°C (68°F)

The range includes rail widths of 7, 9, 12 and 15 mm, that are available, depending on type, in four or five different lengths and strokes.

MSQscale 7	MSQS 7-30.20	MSQS 7-40.28	MSQS 7-50.36	MSQS 7-60.50	MSQS 7-70.58
System length in mm	30	40	50	60	70
Max. stroke in mm	20	28	36	50	58

MSQscale 9	MSQS 9-40.34	MSQS 9-50.42	MSQS 9-60.50	MSQS 9-70.58	MSQS 9-80.66
System length in mm	40	50	60	70	80
Max. stroke in mm	34	42	50	58	66

MSQscale 12	MSQS 12-50.45	MSQS 12-60.48	MSQS 12-80.63	MSQS 12-100.70
System length in mm	50	60	80	100
Max. stroke in mm	45	48	63	70

MSQscale 15	MSQS 15-70.66	MSQS 15-90.70	MSQS 15-110.96	MSQS 15-130.102
System length in mm	70	90	110	130
Max. stroke in mm	66	70	96	102

# 2.1 High Speed and Acceleration

High-acceleration applications demand well thought-out solutions. The unique MINISLIDE MSQscale design with integrated cage control fulfills the requirements of the most advanced drive technologies and enables speeds up to 3 m/s and an acceleration of up to 300 m/s<sup>2</sup>.

# 2.2 High Process Reliability thanks to Cage Control



The robust cage control of MINISLIDE MSQscale **A** gear rack pinion on carriage and guideway **B** cage with pinion In applications without cage control a cage is free to move along the longitudinal axis on every linear guideway. The cage generally moves out of the center position as a result of uneven weight distribution, high acceleration, vertical installation or temperature differences. This so-called cage creep compromises the efficiency of every application, since the cage must be centered regularly using corrective strokes at the expense of energy.

MINISLIDE MSQscale products are fitted with a well-engineered, robust cage control system that eliminates cage creep. The gear rack pinion of the control system is directly integrated into the carriages and guideways. The cages and pinions are made from high-quality plastic.

The compact, robust design as well as the minimum of integrated components ensure the highest strength in every commercial situation.

A mechanical limited stroke protects the cage control mechanism and makes installation and maintenance easy (this must not be used during operation as a means to limit stroke).

# 2 MINISLIDE MSQscale Product Characteristics

# 2.3 Maximum Rigidity and Load Capacities



Arrangement of MINISLIDE MSQscale with four circular arc profile tracks in an O shape

MINISLIDE MSQ products have four tracks with a circular arc profile. Their arrangement in the shape of an O ensures large inner spacings. In combination with the tracks offset by 90 degrees, a high level of evenly distributed force from all directions is achieved, as well as torque rigidity.

MINISLIDE products are preloaded with zero backlash. Combined with the high number of rolling elements, a high level of system rigidity and therefore the highest precision are guaranteed.

# 2.4 Reference and Supporting Surfaces



The locating and supporting surfaces of carriages and guideways are designated as follows. The reference side of the carriage is opposite the carriage side with the company logo / type designation. The guideway can be located on both sides.

# 2.5 Running Accuracy and Parallelism of Supporting Surfaces

The tolerance for the straightness of the stroke depends on the length of the guideway. The following table shows the corresponding maximum values. The measurements are taken in an unloaded state on a flat surface.



System length LStraightness of the stroke (horizontally and vertically)30 mm3 μm40 - 80 mm4 μm90 - 130 mm5 μm

Straightness of the stroke



System length L	Parallelism of the supporting surfaces (frictionless table in the center position)
30 mm	12 µm
40 - 80 mm	15 μm
90 - 130 mm	18 µm

Parallelism of supporting surfaces

# 2 MINISLIDE MSQscale Product Characteristics

# 2.6 Tolerance of the Total Height



Tolerance of the total height

# 2.7 Push Force and Preload

The push force is influenced by the preload and the lubricant used. MINISLIDE MSQscale guideways are delivered with zero backlash and slightly preloaded as standard.

# 2.8 Friction and Smoothness

SCHNEEBERGER places high value on smoothness during manufacturing. The accuracy of the surfaces and materials is of the highest priority. This also applies with respect to the rolling elements used, which must satisfy the most stringent quality demands. Under normal operating conditions a coefficient of friction of 0.003 can be assumed.



Components of MINISLIDE MSQscale

The MINISLIDE MSQscale is an optical, incremental measuring system made up of the MINISLIDE MSQ micro frictionless table and the following additional components:

- A Dimensional scale on the guide rail
- B Optical sensor integrated into the carriage
- C Flexible sensor print (must not be exposed to dynamic loads)
- D Interface module

The control cable E must be supplied by the customer and must be a flexible cable where necessary.

There are various structural types of interface modules available. These are described in section 3.2.

With a flexible flat cable (Flat Flex Cable, abbreviated: FFC), which is inserted between the flexible sensor print and the interface module, the interface module can be positioned flexibly. The FFC cables are suitable for dynamic loads. (You can find more information about accessories in section 5)

# 3.1 Dimensional Scale and Optical Sensor

The high-precision dimensional scale is part of the hardened guideway's surface with a scale increment of 100  $\mu$ m. Two LEDs in the sensor illuminate the dimensional scale. Light-dark fields form because of the illumination of the various structured areas on the dimensional scale. These optical signals are detected by the sensor and converted into electrical signals. The raw signals supplied by the sensor are processed by the interface module.

The level of illumination provided by the LEDs is actively controlled. This can counteract the aging of the system and impurities on the dimensional scale are also compensated for.



Sensor principle A Sensor B Guideway with dimensional scale

#### 3.1.1. Reference Marks

Incremental measuring systems cannot determine the exact position when switched on. For this reason the reference track is added alongside the incremental track. One or multiple reference points can be marked on the reference track.



Guideway with dimensional scale

#### Standard version

The following reference positions are defined as standard:

• All sizes of the MSQS 7, size MSQS 9-50.42 and MSQS 9-60.50: within 4 mm of rail center point



Position of the reference mark at all sizes of MSQS7, at size MSQS9-50.42 and MSQS9-60.5

• Other sizes: in the rail center

#### Special versions

Any number of reference marks can be chosen at any position along the reference track. It is necessary for the reference marks to be synchronised with the dimensional scale. Specifically this means that the reference marks can only be placed in multiples of 0.1 mm, since the pitch of the dimensional scale is 0.1 mm.

A minimum distance of 1.5 mm between the reference marks should be maintained. Aditionally, the distance between the end of the incremental track and the reference mark must be at least 2 mm.

**Restrictions:** 

- The attachment holes on guideways of type MSQS7 and MSQS9 are located on the reference track. The reference marks must therefore be BETWEEN the attachment holes for both of these sizes.
- When specifying the reference mark(s), ensure they can be seen by the carriage's sensor.

# 3 MINISLIDE MSQscale Working Method and Components

# 3.2 Interface Module



Components of the interface module

The raw signals are processed by the interface module and converted to standard output signals. Analog or digital interface modules are available.

Ensure the ZIF connector F is accessible and the LED displays (G and H) on the interface module are clearly visible. Unlike the analog interface, the digital interface includes a compensation key I, which must also be accessible.

- C Flexible Sensor Print
- D Electronics (in various structural types)
- F ZIF connector
- G Green LED (operating voltage)
- H Red LED (error indicator)
- I Compensation key (only on digital interface module)

The interface modules are available in the following structural types:



For customers with expertise in electronics, it is also possible to assemble their own digital interface module and integrate it into their own electronics, in consultation with SCHNEEBERGER.

Order designation: KI

# Reference point Reference point - Sine - Cosine - Reference

3

Differential, analog sin/cos signals with reference pulse

# 3.2.1. Signal Processing

#### Analog output format:

Differential, sin/cos analog signals with reference pulse 1 Vpp



The incremental signals sine and cosine are shifted 90° and correlated with the markings on the encoded scale. An electrical signal period (360°) corresponds precisely to the scale increment of the dimensional scale, which is 100  $\mu$ m.

The sine signal either lags behind the cosine signal or occurs before it, depending on the direction of movement.

The reference pulse width coresponds to about one sine signal period.





# Analog interface module pin connections (1Vpp)

Male 9-pin D-Sub connector or solder terminals:

Pin	Signal	Description					
1	Ua1 -	Quadrature signal					
2	OV	Ground					
3	Ua2 -	Quadrature signal					
4	ERR NOT	Error signal (Low = Error)					
5	Ua0 -	Reference signal					
6	Ua1 +	Quadrature signal					
7	+ 5V DC	Supply voltage					
8	Ua2 +	Quadrature signal					
9	Ua0 +	Reference signal					

Image 1: Pin connections of D-Sub 9 connector at the interface module Image 2: Pin connections at the interface module with solder terminals



Pin connections of Micro Match connector at the interface module

#### Male 10-pin Micro Match connector:

Pin	Signal	Description
1	nc	
2	Ua1 +	Quadrature signal
3	+ 5V DC	Supply voltage
4	Ua2 +	Quadrature signal
5	Ua0 +	Reference signal
6	Ua1 -	Quadrature signal
7	OV	Ground
8	Ua2 -	Quadrature signal
9	ERR NOT	Error signal (Low = Error)
10	Ua0 -	Reference signal



Differential, digital signals with reference pulse

#### Digital output format:

Differentially interpolated digital signals with reference pulse (A, B, R) TTL signal (RS422).



The digital interface module both processes the raw signal and interpolates the processed analog signal. The interpolation achieves a resolution of 100 nm.

The digital signal waveform consists of an A and B signal. The spacing between the two edges of signals A and B correspond exactly to a distance of 100 nm. The 100 µm increments of the encoder scale are consequently divided into 1000 sections of 100 nm by means of interpolation. The A signal either lags behind the B signal or occurs before it, depending on the direction of movement.

The reference pulse is as wide as the spacing between the two signal edges of signals A and B (as wide as one resolution).

The edges of the incremental and reference signals are synchronised.





## Digital interface module pin connections (TTL)

Male 9-pin D-Sub connector or solder terminals:

Pin	Signal	Description
1	A -	Quadrature signal
2	OV	Ground
3	В -	Quadrature signal
4	ERR NOT	Error signal (Low = Error)
5	R -	Reference signal
6	A +	Quadrature signal
7	+ 5V DC	Supply voltage
8	B +	Quadrature signal
9	R +	Reference signal

Image 1: Pin connections of D-Sub 9 connector at the interface module Image 2: Pin connections at the interface module with solder terminals



Pin connections of Micro Match connector at the interface module

14

#### Male 10-pin Micro Match connector:

Signal	Description
nc	
A +	Quadrature signal
+ 5V DC	Supply voltage
B +	Quadrature signal
R +	Reference signal
A -	Quadrature signal
0V	Ground
В -	Quadrature signal
ERR NOT	Error signal (Low = Error)
R -	Reference signal
	Signal nc A + + 5V DC B + R + A - OV B - ERR NOT R -

# 3 MINISLIDE MSQscale Working Method and Components

# 3.3 Lubrication

Lubrication is a design element and must therefore be defined during the development phase of a machine or application.

Standard lubrication for MINISLIDE MSQscale is Klüber Microlube GL 262. This grease has an ideal lubrication effect in the boundary friction area and is suitable for normal and short stroke applications.

Special lubricants are used for specific purposes. For example lubricants for use in vacuums, cleanrooms, for high or low temperatures, for high speeds or high-frequency strokes. SCHNEEBERGER can deliver the guideways with the appropriate lubricant for any of these areas of application.

## 3.3.1. MINISLIDE MSQscale Initial Lubrication

MINISLIDE MSQscale products are lubricated with Klüber Microlube GL 262 at the factory. The systems are delivered ready-to-install. There is no need for an additional initial lubrication.

#### 3.3.2. MINISLIDE Subsequent Lubrication Intervals

The subsequent lubrication interval depends on different influencing variables, e.g. load, working environment, speed, etc. and can therefore not be calculated. The lubrication area should therefore be monitored over a longer period.

The initial factory lubrication can, depending on the operating conditions, suffice for years.

For relubrication, use the original grease only. Keep lubricant quantities low. Overlubrication can cause failure of the optical sensor.

Further information about lubrication is available in the MINISLIDE MSQscale mounting instructions.



# 4.1 Interface Modules

Δ

The interface modules are available in the structural types described in section 3.2.

# 4.2 Digital Interface Module Resolution

The standard resolution of the digital interface module is 0.1  $\mu m.$  Resolutions of 1  $\mu m$  or 10  $\mu m$  can be supplied as an option.

# 4.3 Height Adjusted (HA)

The standard height of the MSQscale is  $\pm$  20  $\mu m$ . This tolerance can be too large for certain configurations, for example, when the carriage spacing  $L_b$  is smaller than the carriage length L. In such cases, the height tolerances can be reduced on a customer-specific basis down to  $\pm$  3  $\mu m$ .



# 4.4 Customer-specific Lubrication (KB)

Special lubricants are used for specific applications. For example, lubricants for use in vacuums, cleanrooms, the food industry, high or low temperatures, high speeds and high-frequency strokes. SCHNEEBERGER can supply the MSQscale with application specific lubrication.

Further tested lubricants:

- High speed / Low Temperatures
- Clean room
- Vacuum
- Food

Klüber Isoflex NBU 15 Klübersynth BEM 34-32 Castrol Braycote 600EF Klübersynth UH1 14-31

# 4.5 Linearity Protocol

For every system, a linearity protocol of the dimensional scale is created. The protocol can be included with each shipment if requested. In order to compensate for linearity deviations in the customer's own application, the protocol can also be requested in an electronic format.



# 5 Accessories

# 5.1 Extensions



Installation example of MINISLIDE MSQscale with FFC extension

Wherever the interface module cannot be mounted directly at the sensor, the extension kit can be used. A flexible flat cable (Flat Flex Cable, abbreviated: FFC) is used between the sensor print and the interface module.

This offers the following benefits:

- By moving the interface module, the mass of the moving system can be reduced by moving the interface module to a non-moving location.
- The shielded FFC cable included in the extension set is also designed to be dynamically loaded. The minimum recommended bending radius is 10 mm. In contrast, the flexible sensor print can only be installed statically.
- The FFC cable provides a low push force. This can be a benefit wherever a cable that can be used in a cable carrier is too rigid.
- The FFC cable can also be folded once during installation.

\*\*

FFC cable with adapter

FFC cables are available in three lengths: 250 mm, 400 mm and 600 mm. An adapter board is delivered with the FFC extension cable.



### Adapter

It is used for the electrical connection between the sensor print and the extension cable. Two ZIF connectors are available on the adapter for this purpose.





#### Clamp plate

Can be used for stress relief or to guide the FFC cable. Two M3 spacer sleeves are installed on the board.





# Base plate

Can be used as a base or for clamping the cable.



Accessories

5 Accessories

# 5.2 MINISLIDE MSQscale Counter and Position Indicator

Heiling & Schweb anthit & Co. KG Bissels Bao Scalarmenn USB-Counter O20 N TTL / I VOS

1-axis USB Counter

#### 5.2.1. 1-axis USB Counter

The USB counter allows a MINISCALE PLUS or similar incremental encoder with TTL, 1 Vpp, or 11  $\mu$ Ass signal output to be connected directly to a computer using a USB interface.

For simple applications, experimental or prototype setups, we recommend the USB counters from Heilig & Schwab GmbH & Co. KG. The following counters can be ordered directly from Heilig & Schwab GmbH & Co. KG (www.heilig-schwab.de).

With the included driver software, the USB counter can be quickly and easily integrated into your application.



3-axis USB Counter

0	UCount basic	8 = 0 = 6	
x		183.367	
z		-75.644	
d		107.723	
A1		46.5°	
	\$8.50		

Digital display program "UCount basic"

# 5.2.2. 3-axis USB Counter

The USB counter allows three MINISCALE PLUS or similar incremental encoders with TTL, or 1 Vpp signal output to be connected directly to a computer using a USB interface. Every counter input additionally has a latch signal input at its disposal.

With the included driver software, the USB counter can be quickly and easily integrated into your application.

#### 5.2.3. "UCount basic" Digital Display Program

UCount basic is a digital display program for the evaluation of linear and angle sensors, which are connected to a computer (PC, laptop or tablet) via USB counters from Heilig & Schwab GmbH & Co. KG. Alternatively, the counters can also be connected to the computer via WLAN.

- Simple operation and clear presentation of all functions
- Meter display of up to 9 signal inputs
- Meter stop function
- Audible meter monitoring (threshold value)
- Calculation functions (addition, subtraction)
- Measuring functions (spacing, angle, included angle, radius)
- Correction function (linear correction, step-by-step (SBS) correction, parallelism correction)
- Reference point administration
- Expandable based on customer preference

#### System requirements:

- PC, laptop or tablet
- Windows Operating System, 32 or 64-bit version
- USB or WLAN interface

#### 6.1 MSQS 7



	Name		Sizes							
	Nam	e	MSQS 7-30.20	MSQS 7-40.28	MSQS 7-50.36	MSQS 7-60.50	MSQS 7-70.58			
	А	System height	8	8	8	8	8			
	A1	System height with sensor	9.2	9.2	9.2	9.2	9.2			
	В	System width	17	17	17	17	17			
	B1	Rail width	7	7	7	7	7			
	B2	Distance between locating surfaces	5	5	5	5	5			
	J	Carriage height	6.5	6.5	6.5	6.5	6.5			
	J1	Rail height	4.5	4.5	4.5	4.5	4.5			
	Н	Stroke	20	28	36	50	58			
	L	System length	30	40	50	60	70			
	L1	Attachment hole spacing	10	10	10	10	10			
	L2	Attachment hole start/end spacing	10	10	10	10	10			
	L4	Attachment hole spacing	15	15	15	15	15			
Ê	L <sub>5</sub>	Attachment hole start/end spacing	7.5	5	10	7.5	5			
un s	Ν	Lateral attachment hole spacing	12	12	12	12	12			
sions	е	Thread	M2	M2	M2	M2	M2			
men	f1	Attachment hole diameter	2.4	2.4	2.4	2.4	2.4			
ō	f2	Screw hole diameter	4.2	4.2	4.2	4.2	4.2			
	g	Usable thread length	3	3	3	3	3			
	<b>g</b> 1	Clamping length	2.2	2.2	2.2	2.2	2.2			
		Ball diameter	1	1	1	1	1			
	f3	Distance to first through hole	5.7	6	7	15	15			
	f4	Spacing of through hole	-	28	36	30	40			
	f5	Lateral spacing of through hole	8.5	8.5	8.5	8.5	8.5			
	S	Sensor Mid-point	15	20	25	30	35			
	<b>S</b> 1	Spacing from sensor	3.7	3.7	3.7	3.7	3.7			
	<b>S</b> 2	Sensor width	5.4	5.4	5.4	5.4	5.4			
	<b>S</b> 3	Sensor length	13	13	13	13	13			
	<b>S</b> 4	Length of the sensor print	75	75	75	75	75			
	<b>r</b> min	Permissible bending radius	2	2	2	2	2			
acity V)	Co	Static load capacity	1193	1670	2148	2386	2864			
(1 Capi	С	Dynamic load capacity ( C100)	609	770	919	989	1124			
	Moq	Permissible lateral static torque	5.1	7.2	9.2	10.3	12.3			
ane	Mol	Permissible static torque lengthwise	5	8.6	13.1	15.8	21.8			
(N	Ma	Permissible lateral dynamic torque	2.6	3.3	4	4.3	4.8			
	ML	Permissible dynamic torque lengthwise	2.5	4	5.6	6.5	8.5			
Weight (g	)		24.5	32.6	40.5	48.5	56.3			

# 6.2 MSQS 9



	Nom	•			Sizes				
	Nam	e	MSQS 9-40.34	MSQS 9-50.42	MSQS 9-60.50	MSQS 9-70.58	MSQS 9-80.66		
	А	System height	10	10	10	10	10		
	В	System width	20	20	20	20	20		
	B1	Rail width	9	9	9	9	9		
	B <sub>2</sub>	Distance between locating surfaces	5.5	5.5	5.5	5.5	5.5		
	J	Carriage height	8	8	8	8	8		
	J <sub>1</sub>	Rail height	5.5	5.5	5.5	5.5	5.5		
	Н	Stroke	34	42	50	58	66		
	L	System length	40	50	60	70	80		
	L1	Attachment hole spacing	10	10	10	10	10		
	L2	Attachment hole start/end spacing	10	10	10	10	10		
	L4	Attachment hole spacing	20	20	20	20	20		
	L <sub>5</sub>	Attachment hole start/end spacing	10	5	10	5	10		
(mm	Ν	Lateral attachment hole spacing	15	15	15	15	15		
) suo	е	Thread	M3	M3	M3	M3	M3		
ensic	f1	Attachment hole diameter	3.5	3.5	3.5	3.5	3.5		
Dime	. f2 Screw hole dia	Screw hole diameter	6	6	6	6	6		
	g	Usable thread length	3	3	3	3	3		
	g1	Clamping length	2	2	2	2	2		
		Ball diameter	1	1	1	1	1		
	f3	Distance to first through hole	10	10	15	15	15		
	f4	Spacing of through hole	-	30	30	40	50		
	f5	Lateral spacing of through hole	10	10	10	10	10		
	S	Sensor Mid-point	20	25	30	35	40		
	S1	Spacing from sensor	4.2	4.2	4.2	4.2	4.2		
	<b>S</b> 2	Sensor width	5.4	5.4	5.4	5.4	5.4		
	S3	Sensor length	13	13	13	13	13		
	<b>S</b> 4	Length of the sensor print	75	75	75	75	75		
	ľmin	Permissible bending radius	2	2	2	2	2		
ad acity	Co	Static load capacity	1432	1909	2386	2864	3341		
cap: (1	С	Dynamic load capacity (≙ C100)	692	846	989	1124	1252		
	Μοα	Permissible lateral static torque	7.6	10.1	12.6	15.2	17.7		
ane due	Mol	Permissible static torque lengthwise	6.7	10.8	15.8	21.8	28.7		
Jor N	Μα	Permissible lateral dynamic torque	3.7	4.5	5.2	6	6.6		
	ML	Permissible dynamic torque lengthwise	3.2	4.8	6.5	8.5	10.7		
Weight (g	)		45.6	56.9	68.1	79.2	90.3		

#### 6.3 **MSQS 12**



	Name		Sizes						
	Nali	e	MSQS 12-50.45	MSQS 12-60.48	MSQS 12-80.63	MSQS 12-100.70			
	А	System height	13	13	13	13			
	В	System width	27	27	27	27			
	B1	Rail width	12	12	12	12			
	B <sub>2</sub>	Distance between locating surfaces	7.5	7.5	7.5	7.5			
	J	Carriage height	10	10	10	10			
	J1	Rail height	7.5	7.5	7.5	7.5			
	Н	Stroke	45	48	63	70			
	L	System length	50	60	80	100			
	L1	Attachment hole spacing	15	15	15	15			
	L2	Attachment hole start/end spacing	10	7.5	10	12.5			
	L4	Attachment hole spacing	25	25	25	25			
	L <sub>5</sub>	Attachment hole start/end spacing	12.5	5	15	12.5			
(mm	Ν	Lateral attachment hole spacing	20	20	20	20			
) su	е	Thread	M3	M3	M3	M3			
insic	f1	Attachment hole diameter	3.5	3.5	3.5	3.5			
Dime	f2	Screw hole diameter	6	6	6	6			
	g	Usable thread length	3.5	3.5	3.5	3.5			
	g1	Clamping length	3	3	3	3			
		Ball diameter	1.5	1.5 1.5		1.5			
	f3	Distance to first through hole	10	15	17.5	20			
	f4	Spacing of through hole	30	30	45	60			
	f5	Lateral spacing of through hole	13.5	13.5	13.5	13.5			
	S	Sensor Mid-point	25	30	40	50			
	S1	Spacing from sensor	6.7	6.7	6.7	6.7			
	<b>S</b> 2	Sensor width	5.4	5.4	5.4	5.4			
	<b>S</b> 3	Sensor length	13	13	13	13			
	<b>S</b> 4	Length of the sensor print	75	75	75	75			
	ľmin	Permissible bending radius	2	2	2	2			
ad acity	Co	Static load capacity	2685	3759	5370	7518			
Cape Cape	С	Dynamic load capacity (≙ C100)	1427	1806	2318	2934			
	Μοα	Permissible lateral static torque	18.9	26.5	37.9	53			
ane m	Mol	Permissible static torque lengthwise	15.7	27	49.5	90.1			
NI (NI	Ma	Permissible lateral dynamic torque	10.1	12.7	16.3	20.7			
	ML	Permissible dynamic torque lengthwise	8.3	12.9	21.4	35.1			
Weight (g	)		103.9	124.4	165.5	206.5			

# 6.4 MSQS 15



		_		Siz	zes	
	Nam	16	MSQS 15-70.66	MSQS 15-90.70	MSQS 15-110.96	96      MSQS 15-130.102        16        32        15        8.5        12        9.5        102        130        20        15        40        5        20        15        40        5        25        M3        3.5        6        4        5        25        M3        3.5        6        4        5        25        M3        3.5        6        4        5        2        25        80        16        65        8.3        5.4        13        75        2        11456        4820        102        166.6        42.9        70.1        399.5
	А	System height	16	16	16	16
	В	System width	32	32	32	32
	B1	Rail width	15	15	15	15
	B <sub>2</sub>	Distance between locating surfaces	8.5	8.5	8.5	8.5
	J	Carriage height	12	12	12	12
	J1	Rail height	9.5	9.5	9.5	9.5
	Н	Stroke	66	70	96	102
	L	System length	70	90	110	130
	L1	Attachment hole spacing	20	20	20	20
	L2	Attachment hole start/end spacing	15	15	15	15
	L4	Attachment hole spacing	40	40	40	40
	L5	Attachment hole start/end spacing	15	5	15	5
) (mm	Ν	Lateral attachment hole spacing	25	25	25	25
) su	е	Thread	M3	M3	M3	M3
ansic	f1	Attachment hole diameter	3.5	3.5	3.5	3.5
Dime	f2	Screw hole diameter	6	6	6	6
	g	Usable thread length	4	4	4	4
	g1	Clamping length	5	5	5	5
		Ball diameter	2	2	2	2
	f3	Distance to first through hole	15	25	25	25
	f4	Spacing of through hole	40	40	60	80
	f <sub>5</sub>	Lateral spacing of through hole	16	16	16	16
	S	Sensor Mid-point	35	45	55	65
	<b>S</b> 1	Spacing from sensor	8.3	8.3	8.3	8.3
	<b>S</b> 2	Sensor width	5.4	5.4	5.4	5.4
	<b>S</b> 3	Sensor length	13	13	13	13
	<b>S</b> 4	Length of the sensor print	75	75	75	75
	ľmin	Permissible bending radius	2	2	2	2
ad ad	Co	Static load capacity	4773	7637	8592	11456
() Capi	С	Dynamic load capacity (≙ C100)	2611	3628	3940	4820
	Μοα	Permissible lateral static torque	42.5	68	76.5	102
ane m	Mol	Permissible static torque lengthwise	36.7	80.9	99.5	166.6
Lon S	Μα	Permissible lateral dynamic torque	23.2	32.3	35.1	42.9
	ML	Permissible dynamic torque lengthwise	20.1	38.4	45.6	70.1
Weight (g	)		216.2	277.5	338.6	399.5

# 7 Load Carrying Capacity and Service Life

# 7.1 Principles

The load capacities are based on the principles of DIN 636.

In accordance with DIN in most applications a permanent overall deformation of 0.0001 times the rolling element diameter can be permitted without adversely affecting the operating behaviour of the bearing. Consequently, the static load capacity  $C_0$  is set sufficiently high that the aforementioned deformation occurs approximately when the equivalent static load corresponds to the static load capacity. Being guided by the dynamic load capacity C is recommended so that the aforementioned overall deformation does not occur.

The dynamic load capacity C is the load at which a nominal service life L of 100 km of travel distance is achieved. It is important to note when calculating the service life that not only the load, which acts vertically on the guideway, should be taken into account but also the load spectrum of all acting forces and moments.

The service life corresponds to the total travel distance in meters which a guideway facilitates. And this is before any noticeable material fatigue on one of the roller guideway elements. The nominal service life is achieved when 90% of the guideways of identical construction reach or exceed the corresponding travel distances under normal operating conditions.

Critical for the dimensioning of the guideways are the loads occurring proportionally with the dynamic load capacity C.

The dynamic load capacity C as given in the catalog corresponds to ( $\triangleq$ ) the definition of C<sub>100</sub>.

#### Definition of service life

As previously mentioned, the dynamic load capacity  $C_{100}$  is based on a service life of 100 km. Other manufacturers frequently indicate the load capacity  $C_{50}$  for a service life of 50 km. The resulting load capacities from this are more than 20% higher than specified by the DIN ISO standard.

#### Conversion example for ball bearings

Convert  $C_{50}$  load capacities to  $C_{100}$  in accordance with the DIN ISO standard:  $C_{100}$  =  $0.79\cdot C_{50}$ 

Convert C<sub>100</sub> load capacities to C<sub>50</sub>: C<sub>50</sub> =  $1.26 \cdot C_{100}$ 

 $C_{50}$  = dynamic load capacity C in N for 50 km of travel distance  $C_{100}$  = dynamic load capacity C in N for 100 km of travel distance, defined in accordance with DIN ISO standard

# 7 Load Carrying Capacity and Service Life

# 7.2 Calculation of Service Life L in Accordance with the DIN ISO Standard

# 7.2.1. The Formula for Calculating the Nominal Service Life for Ball Guideways in Meters is as follows:

$$L = a \cdot \left(\frac{C_{eff}}{P}\right)^3 \cdot 10^5 \,\mathrm{m}$$

- a = Event probability factor
- $C_{eff}$  = Effective load carrying capacity N
- P = Dynamic, equivalent load in N
- L = Nominal service life in m

### Event probability factor a

The load carrying capacities for roller-contact bearings correspond to the DIN ISO standard. This represents a value from the service life calculation, which has a 90% chance of being exceeded during operational use of the guideway.

If the previously mentioned theoretical service life probability factor of 90% is not sufficient, the service life values will need to be adjusted by a factor a.

Event probability in %	90	95	96	97	98	99
Factor a	1	0.62	0.53	0.44	0.33	0.21

# 7.2.2. The Formula for Calculating Nominal Service Life in Hours is as follows:

$$L_h = \frac{L}{2 \cdot s \cdot n \cdot 60} = \frac{L}{60 \cdot v_h}$$

#### 7.2.3. Effective Load Carrying Capacity Ceff

Constructive and external influences can reduce the dynamic load capacity C of MINI-X products in such a way that  $C_{\text{eff}}$  must be calculated.

$$C_{eff} = f_K \cdot C$$

C<sub>eff</sub> = Effective load carrying capacity N

- $f_{\kappa}$  = Contact factor
- C = Maximum permissible dynamic load carrying capacity in N

## Contact factor fk

If multiple carriages are mounted back-to-back with minimal spacing ( $L_b < L$ ), an even weight distribution will be difficult to achieve due to the manufacturing tolerances of the guideway elements and mounting surfaces. Installation situations such as these can be allowed for with the contact factor fk:



#### 7.2.4. Dynamically Equivalent Load P



The loads (F) acting on a linear guideway system are subject to frequent fluctuations during operation. This set of circumstances should be taken into account when calculating service life. The varying load absorption of the guideway at varying operating conditions during the travel distance is described as being the dynamic equivalent load P.

$$P = \frac{3}{L} \sqrt{\frac{1}{L} (F_1^3 \cdot L_1 + F_2^3 \cdot L_2 + \dots F_n^3 \cdot L_n)}$$

#### Sinusoidal load



# Order designation:

Ordering sequence		100	MSQ- Scale	7-	30.	20-	A-	MG-	0.1-	RS-	SB-	SH-	HA-	КВ
Quantity														
Series	MSQS													
Rail width B1	in mm													
Rail length L	in mm													
Stroke H	in mm													
Analog oder Digital	A, D													
Interface module	MG, OG, NL, MM, KI													
Resolution [µm]	0.1, 1, 10													
Special Reference mark	RS													
Special Drilling pattern	SB													
Special Stroke (1)	SH													
Height-matched	HA													
Customer-specific lubrication	KB													

Legend	:		
А	Analog	KI	Without Interface modul
D	Digital	RS	Special Reference mark
MG	With housing (Standard)	SB	Special Drilling pattern
OG	Without housing	SH	Special Stroke (1)
NL	Only circuit board	HA	Height-matched
MM	Micro Match	KB	Customer-specific lubrication

<sup>(1)</sup> The SH option shortens the stroke according to customer's request and at the same time lengthens the cage to the maximum to enable highest possible loads.

# **Options:**

The options must be ordered separately:

Order number	Article
556 100 151	Base plate
556 100 152	Clamp plate
556 100 160	FFC extension cable 250 mm including Adapter
556 100 161	FFC extension cable 400 mm including Adapter
556 100 162	FFC extension cable 600 mm including Adapter

#### SCHNEEBERGER AGENCIES

EUROPE

# AUSTRIA

Haberkorn GmbH 6961 Wolfurt +43 5574 695-0 Phone: +43 5574 695-99 Fax: info.wolfurt@haberkorn.com

### **BULGARIA / MACEDONIA**

Atlas Technik EOOD Hippodroma, Bl. 139B, Eing. A, App. 6 1612 Sofia, PB 51 Bulgarien Phone +359 2 859 76 81 +359 2 859 76 81 Fax Mobile +359 8 852 32 595 E-Mail: al popoff@atlas-technik.com

#### CROATIA

Haberkorn CRO d.o.o. 10431 Sveta Nedelja +385 1 333 5870 +385 1 337 3902 Phone Fax E-Mail: info@haberkorn.hr

#### CZECH REPUBLIC

INOMECH s.r.o. Martina Koláře 2118 390 02 Tábor +420 381 252 223 Phone E-Mail: inomech@inomech.com

#### DENMARK

HERSTAD + PIPER A/S Jernholmen 48c 2650 Hvidovre +45 367 740 00 +45 367 777 40 Phone Fax E-Mail: mail@herstad-piper.dk

#### FINLAND

EIE Maskin OY PL, 80 Asematie 1 10601 Tammisaari +358 192 239 100 Phone +358 192 239 199 Fax E-Mail: info@eie.fi

#### FRANCE

**Region Rhône-Alpes** Groupe BARET

6 avenue du 11 novembre 1918 69200 Venissieux +33 4 78 77 32 32 Phone +33 4 78 00 90 00 Fax E-Mail: contact@baret.fr

Regions IIe de France, Normandie, Bretagne Groupe LECHEVALIER 56 rue Jean Mermoz Parc d'activités de la Bretèque 76230 Bois-Guillaume Cedex Phone +33 2 35 12 65 65 +33 2 35 59 89 97 Fax E-Mail: contact@lechevalier-sa.com

#### Region Nord Pas de Calais

LEFRANC LTL «Le Panetier» 35, rue Pierre Martin Parc d'Activités de l'Inquétrie 62280 Saint Martin Boulogne +33 3 21 99 51 51 Phone +33 3 21 99 51 50 Fax E-Mail: lefranc.boulogne@lefranc-sa.fr

#### GERMANY

BGP-Blazevic Geradlinige Präzisionstechnik Stipo Blazevic Auerbacher Straße 8 93057 Regensburg +49 941 463 704 0 Phone +49 941 463 704 50 +49 151 401 126 25 Fax Mobile E-Mail: info@bgp-blazevic.de

EUROPE

#### HUNGARY

Haberkorn Kft. Asztalos Sándor u.12 Budapest, 1087 Phone +36 13030325 +36 1/3030262 Fax E-Mail: office@haberkorn.hu

#### ITALY

Gruppo Rinaldi Via Campana, 233G 80078 Pozzuoli (NA) Phone +39 081 853 085 6 +39 081 303 049 8 Fax E-Mail: info@grupporinaldi.it

Nadella S.r.l. Via Melette, 16 20128 Milano Phone +39 022 709 329 7 Fax +39 022 551 768 E-Mail: customer.service@nadella.it

### NORWAY

EIE Maskin AS Tvetenveien 164 0671 Oslo Phone +47 675 722 70 +47 675 722 80 Fax E-Mail: elmeko@elmeko.no

#### POLAND

**TECHNIKA LINIOWA** Rollico Rolling Components UI. Cegielniana 21 42-700 Lubliniec +48 343 510 430 Phone +48 343 510 431 Fax E-Mail: rollico@rollico.com

#### ROMANIA

Meximpex SRL 4, Burebista Blvd., bl. D13 sc. A et 2 ap. 9-10 031108 Bucharest +40 213 166 843 /44 Phone Fax +40 213 166 846 E-Mail: office@meximpex.ro

#### RUSSIA

Bearing Alliance, TD 121069 Moscow +7495 987 32 92 add 114, Phone 8 800 100 42 92 Fax. +7495 987 32 92 E-Mail: 114@9873292 ru

#### SERBIA/MONTENEGRO

Haberkorn d.o.o. Kralja Petra I, 59 21203 Veternik, Phone +381 21 820 188 Fax +381 21 820 071 E-Mail: office@haberkorn.rs

#### SLOVAKIA

KBM, s.r.o. Juraj Hajovsky Zitná 13 010 04 Zilina +421 417 070 324 Phone +421 417 070 333 Fax +421 090 585 1465 Mobile E-Mail: jhajovsky@kbm.sk

#### SLOVENIA / BOSNIA HERZEGOVINA

Haberkorn d.o.o. Vodovodna ul. 7 2000 Maribor Phone +386 2 320 67 10 +386 2 320 67 30 Fax E-Mail: info@haberkorn.si

#### EUROPE

#### SPAIN / PORTUGAL

TECNOMECA-KIDELAN-DEXIS Pol Industrial Itziar 20829 DEBA (Gipuzkoa) Phone +34 943 199 201 +34 943 199 273 Phone E-Mail: tecnomeca@tecnomeca.com

#### SWEDEN

EIE Maskin AB Box 7 12421 Bandhagen Phone +46 87 278 800 +46 87 278 899 Fax E-Mail: eie@eie.se

#### TURKEY

Birlik Rulman (Paz.ltd.sti.) Mumhane Cad. No: 16 80030 Karakoy-Istanbul Phone +90 212 249 54 95 +90 212 244 21 40 Fax E-Mail: birlik@birlikrulman.com

Mustafa Kozanlı Mühendislik Ltd. Sti. Çalı Kavşağı Alaaddinbey Cad. No: 7 16130 Nilüfer / BURSA +90 224 443 26 40 Phone Fax +90 224 443 26 E-Mail: satis@kozanli.com.tr +90 224 443 26 39

#### ASIA

#### TAIWAN / REPUBLIC OF CHINA

Ever Bright Systems Co., Ltd. 1F., No. 52, Lane 10, Chi-Hu Road 11492, Taipei +886 2 2659 7881 Phone Fax +886 2 2659 7831 E-Mail: sales@everbright.com.tw

#### INDIA

Jagat Enterprise 83, Narayan dhuru street, 3rd floor, Mazjid Bunder Mumbai - 400 003 +91 2223421941 +91 2223413405 Phone Fax E-Mail: jagatent@gmail.com

M.R. Bearing Company MR Complex, 224 Linghi Chetty Street Parrys, Chennai - 600001 Phone +91 4425232847 +91 4425264497 Fax E-Mail: info@mrbearing.in

#### ALISTRALIA / NEW ZEALAND

Benson Machines 118 Carnarvon Street NSW 2128 Silverwater Australia Phone +61 1800 68 78 98 +61 (02) 9737 9707 Fax E-Mail: info@bensonmachines.com

#### SOUTH AFRICA

Fischli & Fuhrmann Ltd. P.O Box 253 
 Problem
 <t F-Mail: info@fifu.co.za

#### SOUTH AMERICA

Ibatech Tecnologia Ltda. Estrada da Arrozeira, 90 – Residencial Eldorado 92990-000 Eldorado do Sul Brazil Phone +55 51 3337 2870 (RS) +55 19 3483 0007 (SP) Phone E-Mail: vendas@ibatech.com.br

#### SWITZERLAND

SCHNEEBERGER AG Lineartechnik St. Urbanstrasse 12 4914 Roggwil/BE

↓ +41 62 918 41 11 +41 62 918 41 00 info-ch@schneeberger.com

#### JAPAN

Nippon SCHNEEBERGER K.K. Crane Toranomon Bldg 7F 3-20-5 Toranomon, Minato-ku Tokyo 105-0001

日本シュネーベルガー株式会社 〒105-0001 東京都港区虎ノ門3-20-5 クレイン虎ノ門ビル7階

+81 3 6435 7474 +81 3 6435 7475 5 info-j@schneeberger.com GERMANY

SCHNEEBERGER GmbH Gräfenau 75339 Höfen/Enz

+49 7081 782 0 +49 7081 782 124 <u>ر</u> info-d@schneeberger.com

#### CHINA

CHINA

SCHNEEBERGER (Shanghai) Co., Ltd. Rm 606, Shang Gao International Building No. 137 XianXia Road 200051 Shanghai

施耐博格(上海)传动技术有限公司 上海市长宁区 仙霞路137号盛高国 际大厦606室,上海 200051

5 +86 21 6209 0027 +86 21 6209 0102 info-cn@schneeberger.com ITALY SCHNEEBERGER S.r.I.

Via Soldani 10 21021 Angera (VA)

+39 0331 93 20 10 +39 0331 93 16 55 **ر** info-i@schneeberger.com

#### KOREA

SCHNEEBERGER Korea Ltd. Garden5 Tool 10, Chungmin-ro, Songpa-gu, Seoul, Korea 05840

슈니베거코리아 유한회사 05840 서울시 송파구 충민로 10 가든파이브 툴관 10층

+82 2 554 2971 +82 2 554 3971 C IIII info-kr@schneeberger.com

A.MANNESMANN A MEMBER OF SCHNEEBERGER LINEAR TECHNOLOGY

L

USA

SCHNEEBERGER Inc.

Woburn, MA 01801-1759

44 Sixth Road

SINGAPORE

SCHNEEBERGER India Pvt. Ltd. 406. Satra Plaza. Palm Beach Road, Sector 19D Vashi 400 703 New Mumbai

+1 781 271 0140 +1 781 932 4127 info-usa@schneeberger.com

SCHNEEBERGER Linear Technology Pte. Ltd. 38 Ang Mo Kio Industrial Park 2 #01-04, Singapur 569511

+ 65 6841 2385 + 65 6841 3408

info-sg@schneeberger.com

CZECH REPUBLIC

SCHNEEBERGER Mineralgusstechnik s.r.o Prumyslový park 32/20 350 02 Cheb - Dolní Dvory

+420 354 400 941

+420 354 400 940

137 Hanjiang Road Changzhou New district 213000 Changzhou, Jiangsu
施耐博格(常州)测试系统有限公司 汉江路137,常州新区,常州213022

SCHNEEBERGER Changzhou

tion Systems Co. Ltc

+86 519 8988 3938 +86 519 8988 5115 info-mineralcasting@schneeberger.com GERMANY

A.MANNESMANN MASCHINENFABRIK GmbH Bliedinghauser Str. 27 42859 Remscheid

+49 2191 989-0 Ē +49 2191 989-201

mail@amannesmann.de

AUSTRIA AND BENELUX SOUTH EAST EUROPE +43 676 935 1035 +31 6 5326 3929 П info-a@schneeberger.com info-nl@schneeberger.com

ISRAEL

ō.

+972 5 0551 7920

info-il@schneeberger.com

DENMARK, SWEDEN

info-nl@schneeberger.com

RUSSIA, BELARUS, UKRAINE +7 985 960 85 53 +38 050 407 6789 +37 529 860 0410

FRANCE

+33 6 33 12 14 26 (West) +33 7 72 55 06 74 (Ost) info-f@schneeberger.com

ANDORRA +34 69 559 05 99 Π

info-es@schneeberger.com

#### GREAT BRITAIN

+44 77 8814 5645

info-uk@schneeberger.com

TURKEY

+ 90 545 320 83 55

info-tr@schneeberaer.com

www.schneeberger.com









A member of SCHNEEBERGER linear technology

+31 6 5326 3929

SPAIN, PORTUGAL,

POLAND, SLOVAKIA, CZECH REPUBLIC +420 6 0278 4077 Π

info-cz@schneeberger.com

info-ru@schneeberger.com

INDIA

C +91 73 0454 0119

info-in@schneeberger.com